




RELAY HOLDER



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

B: (B135)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	
22	23	24	25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40			

A: (B134)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40		
42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60		
61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81