


| TO POWER SUPPLY CIRCUIT |                         |                     |
|-------------------------|-------------------------|---------------------|
| MB-19<br>M/B FUSE NO. 9 | MB-20<br>M/B FUSE NO. 9 | MB-21<br>HORN RELAY |



\*1 : LHD MODEL WITHOUT PUSH BUTTON START : RW  
EXCEPT FOR LHD MODEL  
WITHOUT PUSH BUTTON START : R

ST3

|   |   |   |   |   |   |   |   |
|---|---|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---|---|---|---|---|---|---|---|

B68

|   |   |    |    |    |    |    |
|---|---|----|----|----|----|----|
| 1 | 2 | 3  | 4  | 5  | 6  | 7  |
| 8 | 9 | 10 | 11 | 12 | 13 | 14 |