


TO POWER SUPPLY CIRCUIT		
MB-19 M/B FUSE NO. 9	MB-20 M/B FUSE NO. 9	MB-21 HORN RELAY



*1 : LHD MODEL WITHOUT PUSH BUTTON START : RW
EXCEPT FOR LHD MODEL WITHOUT PUSH
BUTTON START : R

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

1	2	3	4	5	6	7
8	9	10	11	12	13	14